



Installation Instructions for Yardam

Yardam shipped with 2 cleats, 2 halyards, instructions, and all mounting hardware



| | | | | | | | |
|------------------------|-----|-----|----|------|------|------|----|
| Pole Size (ft) | 20 | 25 | 30 | 33 | 35 | 40 | 50 |
| Yardam Size (ft) | 6.5 | 6.5 | 8 | 8/10 | 10 | 10 | 10 |
| Distance from Top (ft) | 6 | 8 | 10 | 11 | 11.5 | 13.5 | 16 |